

	TABLE OF CONTENTS	
1. OVER	/IEW	3
1.1	PRODUCT DESCRIPTION	3
1.2	PRODUCT FEATURE	
1.3	PRODUCT SPECIFICATION	3
1.4	PRODUCT ACCESSORIES INCLUDE	4
1.5	SYSTEM REQUIREMENT	5
1.6	DN-16023 EXTERIOR FUNCTION INTRODUCE	5
1.7	TV_OUT FUNCTION INTRODUCE	6
1.8	PRODUCT SET-UP	7
2. Utilit	IES AND TOOLS	8
2.1	CAM_EZ SEARCH	8
2.2	USE IP-CAM AND TEST THE IMAGE FUNCTION FOR THE FIRST TIME	8
2.3	HOW TO SET UP IP CAM	
2.4	SETTING THE WAY TO OBTAIN THE IP ADDRESS OF IP-CAM	
2.5	IP-CAM NETWORK FRAMEWORK INSTALLATION	
2.6	INSTALLATION FOR IP SHARE	
2.7	INTERNET IP SHARING & AUDIO SETTING	25
3. GETTI	NG STARTED	
3.1	System Login	
3.2		27
3.3	Таке а Shot	
4. Advar	ICED FUNCTION WITH LIVEVIEW	
4.1	IMAGE ADJUSTMENT	
4.2	AVI RECORD SETUP	
4.3	ZOOM IN DISPLAY	
4.4	MOTION DETECTION SETUP	
5. ADVAN	ICED APPLICATION	
5.1	IMAGE SETUP	
5.2		
5.3	EVENT TRIGGER	
5.4	NETWORK SETUP	
5.5	Server Setup	
5.6	Administration Setup	
5.7	SOFTWARE UPDATE	
	Y	АА
APPE	A	3 EZ IPCAM (USING A

.

Н∪в) 45		
APPENDIX B. F	FAQ	53

#### **1. OVERVIEW**

#### **1.1 PRODUCT DESCRIPTION**

DN-16023 is an easy and effective IP Camera product for remote monitoring /administrating. The setup for this device is simply. Built-in Web server allows you to use web browser (e.g., Microsoft IE) through LAN or broadband network in any time and any place. Type the IP address of the IP-CAM camera on the network address line to carry out the works of remote image monitoring and administration. Handle the real-time image of the monitored location.

In addition, the camera supports many network protocols such as PPPoE, DHCP, STATIC IP, DDNS, SMTP, FTP and NTP with high-performance SDRAM control and memory card access. The built-in TV Out decoding/coding device can display the most popular TV screen (supporting NTSC and PAL) in families with combining fast Motion Detection and SD Expansion Card in hardware. Moreover, DN-16023 is equipped with IR LED lightening, so it has the function of night vision. Besides, this device also has the function of recording and real-time photographing. To a family, such remote monitoring can reach professional security and have great fun.

#### **1.2 PRODUCT FEATURE**

- Use standard Web Browser ID to monitor, record, and shot remotely
- Maximum 640x480 Full screen
- > Allow to view images from multi-camera
- > Allow on-line image viewing remotely for multi-user simultaneously
- > Motion Detect, monitor and store triggered photographs at any time for the whole day
- Remote real-time recoding to the device and trigger to sending images to FTP & E-Mail & SD Card & PC
- Support virtual IP and port switch in IP DSALM
- Support several communication protocols, TCP/IP, DHCP, SMTP, FTP, PPPoE, DDNS,
- > Use functional authority setting, name registration and password protection
- Support the dynamic IP network function of DHCP
- Support ADSL network of PPPoE user
- Standard RJ-45 network connector, support 10/100 BaseT network transmission

#### **1.3 PRODUCT SPECIFICATION**

- Image Size: 160x120□320x240□640x480 adjustable
- ◆ Image Quality: Fine Normal Basic adjustable
- ◆ Video Frequency: 50 Hz for PAL□60 Hz for NTSC
- Image Compression Format : M-JPEG
- Focal Distance Range : From 30mm to infinity adjustable

- Digital Zoom : 4X
- Video Recording : Video Frame rate setting : auto; 1, 3, 5, 10, fps
- Motion Detect Trigger Function, image sent to FTP & E-Mail & SD Card & PC
- Support TCP/IP SMTP FTP PPPoE DHCP Protocol
- Network DHCP or manual setting network IP, and support ADSL network of PPPoE user
- Build-in web server and the functions of Active-X and Java
- Remote single picture captured with JPG file format, remote continuous screen recorded with AVI format
- Microphone : High touch 10φ-40db±3
- ◆ TV OUT Video Output: support 50 Hz for PAL□60 Hz for NTSC
- Night vision lightening illumination: Auto and Manual selection, IR LED x 6/ 5φ/850λ
- Standard RJ-45 network connector, support 10/100 Base T network transmission
- 5V/ 1A exterior switching power adaptor
- Power Consumption : 520mA(max)2.0W(max)
- Operating environment :  $5^{\circ}C \sim 40^{\circ}C$
- Storage temperatures :  $-0^{\circ}C \sim 55^{\circ}C$
- ♦ Humidity : 5%~85% non-condensing

#### 1.4 PRODUCT ACCESSORIES INCLUDE



- 1. DN-16023 IP-Camera
- 2. Power adaptor, 5V/ 1A Switching Power adaptor
- 3. Ethernet Cable (red), used to connect to the network card of PC for testing and configuring the product
- 4. Ethernet Cable (blue), used to connect to Hub, ADSL modem, IP Share
- 5. TV OUT A/V Cable
- 6. Setup CD

- 7. This User's Guide
- 8. Accessory for hanging and fastening

#### 1.5 SYSTEM REQUIREMENT

PC

- Processor: Intel Pentium 4 ® 1.4GHz or above is recommended
- RAM: 256MB or above
- Operation System: Windows 2000<sup>®</sup> or Windows XP<sup>®</sup>
- Hard Disk: Minimum 10MB or above

Network

- Network Card: 10/100 base T
- Network Setup: Accessing Internet normally
- Web Browser: Microsoft Internet Explorer 6.0 or above
- Connect Network Equipment: ADSL modem, IP Share or Hub
- Active-X for activating control items and plug-in

#### **1.6 DN-16023** EXTERIOR FUNCTION INTRODUCE





Usage of Reset Switch:

SD Card Usage Diagram:

While the system is active normally, press and hold Reset Switch for a short time (about 3 to 5 seconds) till Status LED lights up. The system will restart the device and recover to the factory default settings.



- 1. First, insert the TV\_OUT cable to the place as shown in Figure 1.
- 2. Next, plug in power adapter as shown in Figure 2. Press and hold Reset switch for three seconds. Then, release it. The IP-CAM will access into TV OUT mode.
- 3.TV\_OUT operation description:
  - a. Hold to change mode: For the default setting for TV\_OUT is NTSC system, if you want to use PAL system, please press and hold Reset switch about three seconds to switch between NTSC and PAL systems.
  - b. Push to exit : Press Reset to access into TV screen and adjustable 50Hz,60Hz,Outdoor



#### 2. UTILITIES AND TOOLS

#### 2.1 CAM\_EZ SEARCH

CAM\_EZ Search is an IP search engine offered by this product. It can search IP CAM connected in LAN. Through sending the inquiry of broadcasting packets, after IP CAM responds the question, the window will display a list of all IP CAMs in the network. And it allows you to modify the network settings of specified IP CAM, such as IP address or IP CAM naming.



#### 2.2 USE IP-CAM AND TEST THE IMAGE FUNCTION FOR THE FIRST TIME

□ The following connection is suitable for IP-CAM test/fixed IP address change/program code update (strongly recommended).

The operation steps are listed below:

- A. Installing the Product for the first time:
  - You computer must be equipped with network card and RT-45 network connector.
  - Connect the RJ-45 terminator on the rear of IP-CAM to the red test network cable. One end is connected to the network card of computer; the other end is connected to the rear side of the IP-CAM.
  - Connect the power adaptor to the power port (on the rear) of IP-CAM. Now, the status LED on the top of IP-CAM will light up.



B. Check if the IP addresses for PC network and CAM\_EZ Search are on the same network section:

- Usually, static IP address will be used to access into Internet, so the IP address will vary. When you want to change IP address, please write down the original IP address on your computer first. Then you have to modify the IP address of your computer for testing if the IP-CAM can be operated normally or not. After finishing the test, IP address for your computer should be recovered to original settings.
- In general, the IP address for your computer in LAN will be set with "Auto Obtain IP address". To test if the IP-CAM is normal or not, the IP address of your computer must be changed temporarily. After finishing the test, it can be recovered to original settings.
- C. Next, choose Control Panel->Network Connections->choose the activated area

Network Connections---> right click your mouse --->select Properties(P)---> Select Internet Protocol (TCP/IP)---> Select Properties(R), then you can check the current IP address status for the computer. The way to modify IP address is:



D. Open and execute CAM\_EZ Search (as shown in Figure 2). The system will scan the IP-CAM that you just installed automatically. Then, you will find 255IP CAM in the column of Camera Lists. Click 255IP CAM with left mouse button. You can see the default settings for IP-CAM.



Step 1. Click Update. You can see 255DN-16023. Step 2. Click 255DN-16023. You can see Name : DN-16023 IP : 192.168.9.1 SubMask 255.255.255.0 GateWay 0192.168.9.254 HTTP Port Http communication port. The default setting is 80. UDP Port : UDPport, Per-seting is 1500 Step 3. Make sure the IP setting is STATIC. Step 4. Double click on 255DN-16023 to open the browser. Type ID/Password to access into network monitoring screen (for detailed information, please refer to 3.1). If you can see the image screen, it means

#### 2.3 HOW TO SET UP IP CAM

Before you set up IP CAM, you have to know the network environment and if the IP address is fixed or float that provided by your ISP. If you do not know, please contact with your ISP. Section 2.5 will list the common network structure ( $1 \sim 7$  types). Users can refer to the structure to find out what type is suitable for his/her computer and finish the setting up according to the instructions. To set up IP-CAM and IP address, the common way that people use is to change the obtaining of IP address of IP-CAM. Detailed information is listed as 2.4-1 ~ 2.4.3.

### 2.4 SETTING THE WAY TO OBTAIN THE IP ADDRESS OF IP-CAM 2.4-1 STATIC - IP Address Setting

- You computer must be equipped with network card and RT-45 network connector.
- Connect the RJ-45 terminator on the rear of IP-CAM to the red test network cable. One end is connected to the network card of computer; the other end is connected to the rear side of the IP-CAM.
- Connect the power adaptor to the power port (on the rear) of IP-CAM. Now, the status LED on the top of IP-CAM will light up.



 Open and execute CAM\_EZ Search (as shown in Figure 3). The system will scan the IP-CAM that you just installed automatically. Then, you will find 255IP CAM in the column of Camera Lists. Click 255DN-16023 with left mouse button. You can see the default settings for IP-CAM.



• Fill in Fixed IP Address as below. (If you do not know your fixed IP address, please contact with your ISP. Below is an example of Fixed IP Address modification.)



#### Example:

- 1. Set up the IP CAM with fixed IP address.
- Turn on your computer and open IE browser. Type 211-78.174.94:(1025
  1026
  1039....) in the Address line. Now you can access into the monitoring
  screen of network.



#### 2.4-2 DHCP - IP Address Setting:

 Use RJ-45 Ethernet cable (red) to connect ADSL host and switching hub. Then use RJ-45 Ethernet cable (blue) to connect PC and IP CAM (as shown below).



- Connect the power adaptor to the power port (on the rear) of IP-CAM. Now, the status LED on the top of IP-CAM will light up.
- Set up the connection way inside the PC network: Please go to Control Panel ---> Network Connections ---> Choose Activated LAN connection ---> right click your mouse ---> Select Properties(P)---> Select Internet Protocol (TCP/IP)---> Select Properties(R)
   --->Click Obtain an IP address automatically(O), Obtain DNS server address automatically(B).

#### IP CAM User's Guide Pan/Tilt IP Surveillance Camera



 Open and execute CAM\_EZ Search (as shown in Figure 3). Press Update to scan the IP-CAM that you just installed automatically. Then, you will find 255DN-16023 in the column of Camera Lists. Click 255DN-16023 with left mouse button. You can see the default settings for IP-CAM.

CAM EZ Sench V2.6	Step 1. Click Update. You can see 255DN-16023. Step 2. Click 255DN-16023. You can see Name : DN-16023 IP : 192.168.9.1 SubMask 255.255.255.0 GateWay 192.168.9.254 HTTP Port Http communication port. The default setting is 80. Step 3. Choose DHCP. Step 4. After finishing the settings, click Submit. The network settings for DN-16023 IP-CAM will be renewed. (That is, you can obtain a virtual IP address)
Jadas, ok	



#### Example:

- 1. Now, IP-CAM is set up with the IP address in LAN.
- 2. Or, use CAM\_EZ Search to access into monitoring screen of network according to the instructions in Figure 5.
- 3. Or, turn on your PC and open IE Browse. Type 10.1.10.82 in Address lint to access into monitoring screen of network.



#### 2.4-3 PPPoE - IP Address Setting

- Access into monitoring screen of network by following the way stated in 2.2.
- Click Network and open Network menu. Please choose PPPoE and key in the Account and Password. (the following example uses ADSL account from AT&T), press Submit to finish key in and then, please reboot and re-enter.

LiveView	Images	Set Networ	rk Serve	r <u>Administration</u>	EventTrigger	CaptureView	Update
		Network	Setup				
IP Assig	nment	Static	O DHCP	• PPPOE			
			IP 192.16	8.9.1	AC Address	00150f002ad4	
		Subnet	Mask 255.25	5.255.0			
		Ga	iteway 192.16	8.9.254			
	FFFUL	Ac Notice! Clic	k Re-boot button to in	nt@pppoe.com nitialize system is required	Password once PPPoE connecti	on selected	
HTTP S	erver		Port 80		AudioPort	1500	
DNS S	erver		DNS 1 168.95	1.1			
			DNS 2 0.0.0.0	)			

Open CAM\_EZ Search and click Update. Wait for 60 seconds (it varies according to the connection quality). Then the system will search M6820 IP-CAM automatically. 1. Click the searched IP-CAM. 2. Check the IP address and Gateway. Floating IP address, SubMask and Gateway will be shown in dimmed color. It means that IP CAM IP-CAM in LAN has been searched successfully with PPPoE.

ZƏƏIY CAM			IP Assignment: SIAIIC Version:IP_Cam_V2.2_F5
Update 150F001093 -		Exit	]
Name	IP_Cam	PPPOE	Mac 00150F001093
₽ <b>∠.</b>	192. 168. 0. 106	C DHCP	Udp Tool Port 4000
SubMask	255. 255. 255. 0	STATE	PPPoE Account
GateWay	192. 168. 0. 1		PPPoF Password
Ittp Port	80		kolokokok
Audio Port	1500 1500~65535	Submit	]

3. You can also directly use CAM\_EZ Search and key in PPPoE Account & Password.

- Select PPPoE. Click Submit to send out. The IP CAM IP-CAM network settings will be renewed.
- Now you can click the searched IP-CAM to open IE Browser for accessing into IP-CAM web configurator automatically.

2.3 IP-CAWI NETWORK FRAMEWORK INSTALLATION
--

□.	<b>IP-CAM Network Framework Install</b>	ation 1
	Way to access Internet	Use Permanent ADSL or Cable Modem
	Physical IP Address	Owns several physical IP addresses
	IP Share or LAN Hub	General model is OK.
	Network Setup for IP -CAM	LAN Enable / Manually
	Suitable Objects	Users with several physical fixed IP
		addresses and several IP-CAMs installed



- 1. Connect the RJ-45 terminator on the rear of IP-CAM to the red test network cable. One end is connected to the network card of computer; the other end is connected to the rear side of the IP-CAM.
- 2. Refer to 2.4-1 STATIC IP Address Settings to type the IP address properly.
- 3. Set a physical IP address for each IP-CAM.
- 4. Set up the IP-CAM with fixed IP address.
- 5. For viewing images in IP-CAM from remote computer: Open IP browser and type in the physical IP address of the IP-CAM, e.g., http://211.78.174.03.

□.	IP-CAM Network Framework Installation 2	
	Way to access Internet	Use Permanent ADSL or Cable Modem
	Physical IP Address	Owns more than one IP address
	IP Share or LAN Hub	Must be equipped with DHCP function
	Network Setup for IP -CAM	LAN Enable / Manually
		Web Server Port Number, need to be adjusted
	Suitable Objects	Users with one physical fixed IP addresses, IP
		Share and several IP-CAMs installed



- 1. Set a real physical IP address (e.g., 211.78.174.01) for the public IP of IP Share. Then, set another private IP address and activate the DHCP server function of IP Share.
- 2. In the IP configuration for each IP-CAM, please assign different virtual IP address internally and respectively. In the Http Port setting, please specify different port parameters. (Please refer to **2.4-1 STATIC IP Address Settings** to type the IP address properly.)
- 3. For the port transformation in IP Share, please refer to IP and port settings of camera to configure accordingly.
- 4. For viewing images in IP-CAM from remote computer: Open IP browser and type in the physical IP address of the IP Share and the port number of IP-CAM, e.g., http:// 211.78.174.01:1025.

M Network Framework Installa	ation 3
access Internet	Use dial-up ADSL or Cable Modem
	access Internet

Physical IP Address	Owns one float IP address (dispatched by ISP
	dynamically)
IP Share or LAN Hub	Must be equipped with DHCP and NAT
	functions
Network Setup for IP -CAM	LAN Enable / Manually
	Web Server Port Number, need to be adjusted
Suitable Objects	Users with dial-up ADSL, one float IP address
	and several IP-CAMs installed



- 1. Activate PPPoE function of IP share. Then, set another private IP address and activate the DHCP server function of IP Share. When the dial-up of ADSL is successful, you will get an float IP address from your ISP.
- In the IP configuration for each IP-CAM, please assign different virtual IP address internally and respectively. In the Http Port setting, please specify different port parameters. (Please refer to 2.4-1 STATIC - IP Address Settings to type the IP address properly.)
- 3. For the port transformation in IP Share, please refer to IP and port settings of camera to configure accordingly.
  - For viewing images in IP-CAM from remote computer: Open IP browser and type in the float IP address of ADSL and the port number of IP-CAM, e.g., http:// 211.78.174.01:1025.

ſ	Way to access Internet	Use Permanent ADSL or Cable Modem
	Physical IP Address	Owns one physical IP address

IP Share or LAN Hub	Not necessary
Network Setup for IP -CAM	LAN Enable / Manually
	Web Server Port Number, no need to be
	adjusted
Suitable Objects	Users with permanent ADSL, one fixed
	physical IP address and one IP-CAM installed



- 1. Connect the RJ-45 terminator on the rear of IP-CAM to the red test network cable. One end is connected to the network card of computer; the other end is connected to the rear side of the IP-CAM.
- 2. Refer to 2.4-1 STATIC IP Address Settings to typing the IP address properly.
- 3. Set up the IP-CAM with fixed IP address.
- 4. For viewing images in IP-CAM from remote computer: Open IP browser and type in the physical IP address of the IP-CAM, e.g., http://211.78.174.94.

Way to access Internet	Use dial-up ADSL or Cable Modem				
Physical IP Address	Owns one float IP address (dispatched by ISP				

#### D. IP-CAM Network Framework Installation 5

	dynamically)
IP Share or LAN Hub	Not necessary
Network Setup for IP -CAM	PPPoE function should be set, LAN Enable
	Web Server Port Number, no need to be
	adjusted
Suitable Objects	Users with dial-up ADSL, and one IP-CAM
	installed



- 1. Please acquire the necessary information of ADSL dial-up from your ISP. ISP relational information: ADSL dial-up account name and password
- Connect the RJ-45 terminator on the rear of IP-CAM to the red test network cable. One end is connected to the network card of computer; the other end is connected to the rear side of the IP-CAM.
- 3. Refer to **2.4-3 PPPoE IP Address Settings** for typing account name and password.
- 4. Please type the **Mail server setup** information of IP-CAM.
- 5. Set up the IP-CAM to Dial up ADSL Modem.
- 6. When the dial-up is successful, IP-CAM will send a notification e-mail of float IP Address to the users.
- 7. Open IP browser and type in the physical IP address (such float IP is dispatched by ISP) of the IP-CAM, e.g., http://211.78.174.94.

Way to access Internet	Use dial-up ADSL or Cable Modem
Physical IP Address	Owns several float IP addresses
	(dispatched by ISP dynamically)

#### D. IP-CAM Network Framework Installation 6

IP Share or LAN Hub	Must be equipped with DHCP and NAT
	functions
Network Setup for IP -CAM	LAN Enable / Manually
	Web Server Port Number, need to be adjusted
Suitable Objects	Users with several float IP addresses and
	several IP-CAMs installed



- 1. Please acquire the necessary information of ADSL dial-up from your ISP. ISP relational information: ADSL dial-up account name and password
- 2. Connect the RJ-45 terminator on the rear of IP-CAM to the red test network cable. One end is connected to the network card of computer; the other end is connected to the rear side of the IP-CAM.
- 3. Refer to **2.4-3 PPPoE IP Address Settings** for typing account name and password.
- 4. Please type the **Mail server setup** information of IP-CAM.
- 5. Install IP-CAM on LAN Hub.
- 6. Use CAM\_EZ Search tool to find out the float IP address assigned by ISP for the ADSL currently.
- 7. Open IP browser and type in the physical IP address (such float IP is dispatched by ISP) of the IP-CAM, e.g., http://211.78.174.94.
- 8. Follow the steps above to configure for each IP-CAM.
- D. IP-CAM Network Framework Installation 7

Way to access Internet	Use Permanent ADSL or Cable Modem
Physical IP Address	Owns one physical IP address
IP Share or LAN Hub	Must be equipped with DHCP and NAT
	functions
Network Setup for IP -CAM	LAN Enable / Manually

	Web Server Port Number, need to be
	configured
Suitable Objects	Users with one fixed physical IP, IP Share and
	several IP-CAMs installed



- 1. Set a real physical IP address (e.g., 211.78.174.01) for the public IP of IP Share. Then, set another private IP address and activate the DHCP server function of IP Share.
- In the IP configuration for each IP-CAM, please assign different virtual IP address internally and respectively. In the Http Port setting, please specify different port parameters. (Please refer to 2.4-1 STATIC - IP Address Settings to fill in the IP address properly.)
- 3. For the port transformation in IP Share, please refer to IP and port settings of camera to configure accordingly.
- For viewing images in IP-CAM from remote computer: Open IP browser and type in the IP address of IP Share and the port number of IP-CAM, e.g., http:// 211.78.174.01:1025.

#### 2.6 INSTALLATION FOR IP SHARE

When IP-CAM is installed under IP Share, it can obtain a dynamic IP address from DHCP server. If you want to install the IP-CAM in WAN interface, you have to set a fixed IP address for the device. No matter whether your IP Share has the function of virtual server, it is necessary for IP-CAM to set a fixed IP address.

(1) Please use CAM\_EZ Search to set a fixed IP address for IP-CAM, e.g., 192.168.0.120 and change the http port number (1025~35534). (refer to Figure 1)

Figure 1

2551P Cam			IP Assignment: STATIC Version:IP_Cam_V2.2_F5
Update	]	Exit	]
Name IP SubMask	IP_Cam 192.168.0.120 255.255.255.0	C PPPOE C DHCP STATIC	Mac 00150F001093 Udp Tool Port 4000 PPPoE Account
GateWay	192. 168. 0. 1 5000		Account@pppoe.com.tw PPPoE Password
Http Port			

(2) Type admin to access into ADSL router's web configuration. (Refer to Figure 2)

Connect to 192.168	.0.1
1.0	
DI-624	
<u>U</u> ser Name( <u>U</u> ):	🙎 admin
Password(P):	
	Remember my password

(3) Enable DHCP function of IP Share. (Refer to Figure 3. The range of available IP address is 192.168.0.100~192.168.0.199)

Figure 3

24	Home	Advanced	Tools	Status	Help
	DHCP Server				
Wizord	The DI-624 can network	be setup as a DHCP	Server to distribu	te IP addresses to t	he LAN
	DHCP Server	⊙ Ena	bled 🔘 Disable	d	
	Starting IP Addr	ess 192.16	8.0.100		
	Ending IP Addre	ss 192.16	8.0.199		
Ĩ.	Lease Time	1 Weel	( <del>~</del>		
	Static DHCP				
	Static DHCP is address.	used to allow DHCP	server to assign s	ame IP address to	specific MAC
_		O Ena	bled 💿 Disable	d	
	Name				
	IP	192 16	8.0.		

(4) Access into the web page of Virtual Server. Add the fixed IP address specified by CAM\_EZ Search in step (1) and enable it. (Refer to Figure 4.1)

Figure 4.1

Hor	ne Advar	nced To	ols Sto	itus He	elp
Virtual S	erver inver is used to allo	w Internet users	access to LAN serv	ices.	
Name	ieffipcam1	1 O Disabled	Clear		
Private IF	192.168.0.1	120			
Protocol	Гуре ТСР 💌	12			
Private P	ort 5000				
Public Po	rt 5000				
Schedule	Always     Alway     Always     Alw				
	O From t	ime 00 🔽 : 00	) 🗸 AM 🖌 to 00	👻 : 00 🔽 AM	*
	c	Jay Sun 💌 to	Sun 👻		
				🧭 😢	C
	ervers List			Apply Cance	l Hel
Virtual S					
Virtual S Nam	8	Private IP	Protocol	Schedule	
Virtual S Nam	e al Server FTP	Private IP 0.0.0.0	Protocol TCP 21/21	Schedule always	20
Virtual S Nam	e al Server FTP al Server HTTP	Private IP 0.0.0.0 0.0.0.0	Protocol TCP 21/21 TCP 80/80	Schedule always always	

(5) After adding the IP address, you can see **jeffipcam1** in the virtual server list (refer to Figure 4.2).

Figure 4.2

Vir	tual Servers List			Mapply Cancel	C) Help
	Name	Private IP	Protocol	Schedule	
	Virtual Server FTP	0.0.0	TCP 21/21	always	1
	Virtual Server HTTP	0.0.0.0	TCP 80/80	always	
	Virtual Server HTTPS	0.0.0.0	TCP 443/443	always	
	Virtual Server DNS	0.0.0.0	UDP 53/53	always	
	Virtual Server SMTP	0.0.0.0	TCP 25/25	always	
	Virtual Server POP3	0.0.0.0	TCP 110/110	always	
	Virtual Server Telnet	0.0.0.0	TCP 23/23	always	
	IPSec	0.0.0.0	UDP 500/500	always	
	PPTP	0.0.0.0	TCP 1723/1723	always	
	NetMeeting	0.0.0.0	TCP 1720/1720	always	
	DCS-1000	0.0.0.0	TCP 80/80	always	
	DCS-2000/DCS-5300	0.0.0.0	TCP 800/800	always	
	i2eye	U.U.U	TCP 1720/1720	always	
4	jeffipcam001	192.168.0.120	TCP 5000/5000	always	

(6) Restart PC and IP Share. After restarting, if you want to connect IP-CAM from WAN interface, please key in <u>http://59.104.28.251:5000</u> if you wish to link to IP cam (Figure 5)

Figure 5

Home	Advanced	Tools	Status	Help
Device Info	rmation	0.555.5245	A CONTRACTOR OF	
1.00	Firmware Versi	on: 2.55 , Mon,	04 Jul 2005	
LAN				
MAC A	ddress 00-13-46-1c-3c-0	7		
IP As	ddress 192.168.0.1			
Subnet	Mask 255 255 255.0			
DHCP 9	Server Enabled			
WAN				
WAN MAC A	ldress 00-e0-18-fc-8e-9:	5		
WAN MAC Ar Conn	ddress 00-c0-18-fc-8e-90 ection DHCP Client Cor	i wected DHCF	PRelease ) [ [	HCP Renew
WAN MAC A Conn IP A	ddress 00-c0-18-fc-8c-95 ection DHCP Client Cor ddress 59.104.29.91	s wected DHCF	? Release	HCP Renew
WAN MAC Ar Conn IP Ar Subnet	ddress 00-00-18-10-8e-95 ection DHCP Client Con Idress 59:104.29.91 1 Mask 255.255.252.0	5 mected DHCF	P Release	HCP Renew
WAN MAC Ar Conn IP Ar Subnet Default Ga	ddress 00-00-18-fo-8e-95 ection DHCP Client Cor Idress 59:104:29:91 Mask 255:255:252:0 teway 59:104:29:1	i mected DHCF	Release ] [ [	HCP Renew

#### 2.7 INTERNET IP SHARING & AUDIO SETTING

Please use the following steps for setting up if your IP cam does not have Audio Step 1, setting Audio Part : the Pre-setting is 1500 (setting range is 1500~65535) and press Submit

2551P Cam			IP Assignment: STATIC Version:IP_Cam_V2.2_F5
Update 0150F001093 -	]	Exit	]
Name	IP_Cam	C PPPOE	Mac  00150F001093
IP Colomada	192. 168. 0. 120		Udp Tool Port 4000
CaleWay	255, 255, 255, 0	_	Account@pppoe.com.tw
Http Port	5000		PPPoE Password
	1500	submit	1

step 2, add one new UDP part 1500 in router (UDP port setting range is 1500~65535) as one port can only appoint to the use of one IP cam. Therefore, please assign other ports if you have more than two IP cams.

	Virtual Serve	
	Virtual Server i	s used to allow Internet users access to LAN services.
Virtual Server		💿 Enabled 🔿 Disabled
	Name	lieff3Clear
Applications	Private IP	192.168.0.120
	Protocol Type	
Filters	Private Port	1500
	Public Port	L1500
Parental Control	Schedule	Always
		○ From time 00
C. Firewood		day Sun 💌 to Sun 💌
Firewall		
		S 😒 🕄

## 3. GETTING STARTED

#### 3.1 SYSTEM LOGIN

The system login is the process of identifying all users trying to log into the system to

confirm user identify and grant permission to access to the system's functions. This system provides two layers of security access: "administer" and "general user". After a successful login to the system, users can begin to access both surveillance and setting functions, Follow the steps below to log in as an "admin" user:

Step 1: Open the login window, as shown below.

Using the CAM\_EZ Search application, select the IP CAM from the menu, and Double Click on it ;  $\ .$ 

2551P Cam			IP Assignment: STATIC Version: IP_Cam_V2. 2_F5
Update		Exit	]
Name IP	IP_Cam	C PPPOE C DHCP	Mac 00150F001093
SubMask	255. 255. 0. 0	C STATIC	PPPoE Account
GateWay Http Port	80		Account@pppoe.com.tw PPPoE Password
Audio Port	1500 1500~65535	Submit	



Account ID	
Password	

Step 3: Enter Account ID and Password (the default settings are "admin" and "password");

Step.4 Press Submit to confirm, and then follow the instructions for the LiveView feature show on the next page ;

Step.5 If a mistake has been made, press Cancel, and enter login information again.



#### 3.2 LIVEVIEW

When using IP Cam for the first time, users must change the Internet Explorer security settings (please refer to settings step 3.2.1). Otherwise, the system will display the following warning, and be unable to display the surveillance feeds.



After having successfully set up the IP CAM settings during the first use, users do not need to change the settings again for later use.

**3.2.1** The IE security settings can be changed by following the steps below: Step 1. IE Toolbar ---> Tools ---> Internet Options ---> Security ---> Custom Level ...

nternet Op	tions				? 🛛
Genera <mark>,</mark> Se	curity Privacy	Content	Connection	s Programs	Advanced
Select a We	eb content zone	to specify	its security se	attings.	
		net Trus	✓ ted sites		
				sites	
Inte	ernet				
This have	zone contains a en't placed in oth	all Web site her zones	es you	<u>S</u> i	tes
Security Je	evel for this zone				
(	Custom				
	Custom setting	IS.	oliok Custor		
	To use the re	commend	ed settings, c	lick Default Le	evel.
	C	<u>C</u> ustom I	Level	Default L	evel
6		ОК		Cancel	Apply

Step 2. After clicking on Custom Level ..., a security settings window shall appear. Change ActiveX Control Options and Plug-ins settings to the following

- 1. Download signed ActiveX controls: Enable
- 2. Download unsigned ActiveX controls: Enable
- 3. Initialize and script ActiveX controls not marked as safe: Enable
- 4. Run ActiveX controls and plug-ins: Enable
- 5. Script ActiveX controls marked safe for scripting: Enable

HCCN	eX controls and plug-in	5	<u>^</u>
	)ownload signed Active; )ownload unsigned Activ	X controls veX controls	
	nitialize and scrint Activ	eX controls pot m	arked as safe
្ត័	Run ActiveX controls and	d plug-ins	
៍ 🧃 🖥	cript ActiveX controls a	narked safe for so	ripting
Dowi	nloads		
E 🔮	File download		
(	🔵 Disable		
(	🖲 Enable		
📑 F	Font download		
(	) Disable		
(	🥑 Enable		V
<			>
Death			
Reset t	uscom secongs		

Step 3. After pressing "ok", a warning window shall appear. Click on "Yes", and you shall return to the last window. Press "OK", and the setup is complete.



Step 4. At this time, the computer should display a warning window, as shown above : Press "Yes" , to begin;



- Convolution
   Conversion
   Conversion
   Conversion
   Conversion
- Step 5. When the installation is complete, you may begin viewing the surveillance image for the first time, as shown below.

Note: This action loads ActiveX components from the DN-16023 System to the local machine. To ensure your machine cannot run malicious ActiveX content from the Internet without authorization, you will be prompted to allow the ActiveX component of your browser to interact with the DN-16023 each time you access it. When you view the stream from the IP CAM and you see the prompts regarding downloading, running or enabling ActiveX content from the IP address of the DN-16023, click "Yes" to allow your computer to display the video from your camera .If you are prompted to allow ActiveX content when you are not connected to your DN-16023, ensure the provider of the content is a reliable and secure source for running programs on your PC. If you are in doubt about the source of the ActiveX program you are being requested to allow to run on your system, click "No" to ensure you don't allow malicious programs to interfere with your PC.

#### 3.3 TAKE A SHOT

This function allows users to capture the screenshot as a photo, and save it on the computer.

Directions:

- Step 1. Go to the LiveView menu, and go to the live image.
- Step 2: Hold down the Ctrl key on your keyboard;
- Step 3. Place the cursor on the surveillance image and left click with your mouse. The captured image should flash momentarily, as shown below:

(or press the Snapshot button)



- Step 4. Release the **Ctrl** key, and the single still shot image will have been successfully captured.
  - Step 5. Select the **CaptureView** menu to browse through the captured images. Refer to Chapter 5.2 for details.

Note: Snapshot can only be stored to PC, can't store to SD Card

#### 4. ADVANCED FUNCTION WITH LIVEVIEW

Move the cursor to the live image, and right click with your mouse. A small menu should appear with four options.



- Image Adjust image values
- Record Setup for recording into AVI format.
- Zoom Select digital zoom value for window.
- Motion Detect Set Settings for motion detection

These settings are described in detail in the next chapter

#### 4.1 IMAGE ADJUSTMENT

After selecting an Image, you may change various image settings, as shown below:

Brightness	<u> </u>		50	
Contrast	·	F	50	
Saturation	•		50	
Sharpness	•	Þ	0	
Smooth	•	F	0	
Awb		•	0	

#### 4.2 AVI RECORD SETUP

By selecting "Record", you can adjust the AVI Frame Rate settings ad file name.

			320*240 pid 4	
Frame rate	• 1 O 3 O 5 O	10	020 210 pid 4	
Save ac	c:\tmp\webcam\a=00;	2004111658.avi	-	
2016 03	leiterblicerenite ee			
STAR	T STOP			-

#### 4.3 ZOOM IN DISPLAY

Using your mouse, click and drag out a box to select the portion of video that you wish to view as shown by the black box in the image below. The image will zoom in according to the dimensions entered and will show an image similar to this below



#### 4.4 MOTION DETECTION SETUP

Setting up the Motion Detection (MD) values, including the first area (red border) and second area (green border).

Please check to see whether the Event Trigger has been enabled. If so, you can set up Motion Detection as described below:

- Reset MD range: Select motion detect 1or2, and hold down on the left mouse button (this will appear as the upper left corner of the MD range). Then, drag out the desired range, and release when finished.
- Cancel MD: Same as above, but just left click once and release. This will cancel the MD (Motion Detection).
- Motion\_detec\_set: This sets the MD (Motion Detection) sensitivity, which is usually set to a value of 5. This means that the motion detection will be toggled with as little of a 5%

change in the MD range. The lower the number entered, the higher the sensitivity of the MD.

When motion is detected, the screen should display an MD warning in red in the upper left hand corner if there is movement within MD1 or MD2, as shown in below:





- Any motion detection range can be selected in 640x480 and 320x240 resolutions

- In 160x120 resolution, the motion detection is fixed to the entire image.

#### Note:

- 1. Motion Detection can exist PC and SD Card
- 2. Image that MD reaches PC is stored to C: \tmp\webmd

#### 5. ADVANCED APPLICATION

This chapter explains the advanced settings for the IP CAM, including:

- Image Setup
  - Capture View
- Network Setup
- Server Setup
- Event Trigger Setup
- Administration Setup
- Software Update

#### 5.1 IMAGE SETUP

This includes□

- Resolution □ Users can select between image resolution of 160x120, 320x240, and 640x480. The default resolution is 320x240.
- Quality Users can select between "fine", "normal", and "basic" image quality. The default image quality is "basic".
- Anti-Flicker Users can select between 60Hz for USA and Canada, 50Hz for Australia and Europe, or Outdoor for when you are observing a naturally lit outside area; The default setting is 50Hz.
- Audio Audio output. Default setting is "off".
- Rotate 180 This setting turns the image upside-down for when the camera is mounted to

a ceiling; Default setting is "off".

- IR Auto Detection IR LED auto activation in low light. Default setting is "on"

- Message : LiveView characters are hidden Default setting is "on"

Image Setup Directions  $\square$ 

Step 1. Click on **ImageSet** to view the menu, the default settings are shown below;

	Image Setu	lb	
Resolution	●160×120	● 320x240	O 640x480
Quality	• Fine	<ul> <li>Normal</li> </ul>	● Basic
Anti-Flicker	⊙60Hz	⊙50Hz	• Out Door
Audio	ON	● OFF	
Rotate 180 Degree	• on	● OFF	
IR Auto Detection	• ON	OFF	
Message	OON	OFF	

Step 2. After entering the desired values, click on Submit.

Step 3. If you wish to cancel your changes, click on Cancel

#### 5.2 CAPTURE VIEW

This view includes□

- Manual capture of still images using LiveView.
- Automatic capture of still images via MD.

How to Use Capture View□

Step 1. Click on **CaptureView** to enter the menu. The menu is capable of saving up to 48 images, viewable on three pages of. Images saved using Motion Detection will not be shown here;



Step 2. You can set the system to read from either your computer or your SD Memory card. After making your selection, click on Apply.

Step 3. Select desired thumbnail image using the cursor to view image at the default dimensions.



Note: Images seen in <u>CaptureView</u>: PC is the image of Snapshot; FlashCard is the image of MD; The image of MD to PC is stored in C:\tmp\webmd

#### 5.3 EVENT TRIGGER

This includes both event trigger settings and display, including:

- Event Entering events
- Trigger Setting trigger and picture capture times



Detailed explanations are presented in the next chapter.

#### 5.3.1 Event

- Event settings, including:
- Motion Detection (set 1)
- Motion Detection (set 2)

Individual or both set signal input triggers can be seleced.

How to Use Event Settings

Step 1. Activate Event for either set (MD will automatically display the trigger sensitivity)

Step 2. After you are finished, click on Submit, otherwise;

Step 3. Click on **Default** to use factory default settings (sets all to off).

Note: After engaging either type of event, "Save in PC" will automatically turn on.

#### 5.3.2 Trigger

Event trigger image transfer settings, including:

- Save in PC The image file is saved in your computer.
- Save in Flash Card The image file is saved in the SD card.
- Mail Image Send captured event trigger image file by e-mail.
- FTP Image Send captured event trigger image file by FTP.
  - Shutter Timer Change shutter time for event trigger image capture. two (2) seconds is the default setting.

#### 5.4 NETWORK SETUP

Network Setup can be used to change the network connection settings of the IP CAM. The default value for IP assignment is "static". These settings also include:

- IP Assignment Static, DHCP, or PPPoE
- PPPoE settings (PPPoE is the most common type of Broadband Internet connection, where your ISP assigns a different IP address to your connection each time you log on)
- Http Server port settings
- Set the port of UDP Server and also Audio Port
- DNS settings

MAC Address Displays the Mac address of the IP CAM



#### 5.4.1 IP Assignment

Static IP Assignment refers to the fixed settings of the ISP or network engineering department.

IP Address: Includes Static, DHCP and PPPoE. DHCP and PPPoE are typically dynamic IPs where a DHCP server or your ISP designates an IP address each time you log on.

When using the "Static" setting, you must enter the following information:

- IP Address The IP address of the IP CAM
- Subnet Mask Set by default to 255.255.255.0
- Gateway Default gateway

When using the "DHCP" setting, you do not need to enter any of the above settings. You must only enter the address of the DHCP Server in the "Server" field.

When using the "PPPoE" setting, you must correctly enter your ISP Login name and password. Please refer to unit 5.4.2 for details.

#### 5.4.2 **PPPoE**

This menu allows you to enter the dial-up settings during PPPoE IP assignment. This usually refers to entering your ID account name and password. Remember that you must also enter your ISP log-in settings.

How to Setup PPPoE

- Step 1. Enter your correct user ID in the "Account" field.
- Step 2. Enter your correct password in the "Password" field.
- Step 3. Click on **Submit** to complete your settings.
- Note: Because PPPoE utilizes a dynamic IP address from an ISP, the IP settings for the DN-16023 could differ for each use. It is suggested that an IP Router be used to connect to the PPPoE or DDNS. This will assist your computer in finding the IPCAM.

#### 5.4.3 HTTP Server

This menu allows you to enter the port number of the DN-16023 IPCAM internal web server (or HTTP Server) via HTTP protocol. The default port number is "80".

#### 5.4.4 DNS Server

This menu allows you to enter the IP address of the DNS (Domain Name Server). By doing this, you can replace the IP address of the IP CAM with an http name (such as myIPCAM.XXX), making it easier to remember. The default DNS1 value is "168.95.1.1" (Hinet). If the connection fails, the system will automatically attempt to connect to DNS2.

#### 5.5 SERVER SETUP

This menu allows you to enter various server settings, including:

- Mail Server
- FTP Server
- DDNS Server
- NTP Server



#### 5.5.1 Mail Server

This refers to settings pertaining to sending image files via a mail server. You must also make sure that the Mail Image settings from 5.3 **EventTrigger** are enabled to e-mail a file to the designated address upon event trigger. This system supports SMTP (Simple Mail Transfer Protocol) servers.

How to use mail server settings:

Step 1: Enter the IP address or http web address of the mail server in "IP/Host".Step 2: Enter the e-mail address of the sender in "Mail From".Step 3: Enter the e-mail address of the recipient in "Receipt to".Step 4: Enter the registered account ID of the mail server in "Account ID"Step 5: Enter the correct mail server password in "Password"

Step 6: Enter whether or not your mail server requires authorization in "Authorization" Step 7: Click on Submit when you are finished.

#### 5.5.2 FTP Server

This menu allows you to enter the FTP (File Transfer Protocol) Server settings. You must also make sure that the FTP Image settings from 5.3 **EventTrigger** are enabled to send a file to the designated FTP server via FTP upon event trigger. This system supports Port Mode and Passive Mode. You must be able to write to the root folder of the ftp site to use this feature.

How to use FTP Server settings:

Step 1: Enter the IP or HTTP address of the FTP server in "IP/Host"

Step 2: Enter the designated FTP port number in "Port"

Step 3: Enter the account ID of the FTP server in "Account ID"

Step 4: Enter the FTP server password in "Password"

Step 5. Select whether you wish to use "Port Mode" or "Passive Mode" transfer protocol. Step 6. Click on **Submit** when you are finished.

#### 5.5.3 DDNS Server

This menu allows you to enter your DDNS (Dynamic Domain Name Server) Settings. You can also use a PPPoE (with dynamic IP) to connect to the http address of the IPCAM (such as sqipcam.dyndns.org) by entering the registered HTTP address of the DDNS Server. This is convenient for viewing IPCAMS with non-fixed IP addresses.

Entering the DDNS Server Settings

- Step 1: Find a DDNS service (such as <a href="http://www.dyndns.org">http://www.dyndns.org</a> ), and register a user account, password, and HTTP user address.
- Step 2: Enter the address (IP or HTTP) of the DDNS server. Enter the host name, account ID, and password in each appropriate field.
- Step 3: Enter the account ID of the DDNS server in "Account ID"

Step 4: Enter the DDNS server password in "Password"

Step 5. Select the DDNS server connection status automatic display setting.

Step 6. Click on Submit when you are finished.

#### 5.5.4 NTP Server

NTP(Network Time Protocol) allows you to calibrate the IP CAM timing.

Using the NTP Server settings

Step 1: Enter the NTP Server IP or HTTP address in "IP/Host" Step 2: Select the correct time zone in the "Time Zone" menu Step 3: Click on **Submit** when finished.

#### 5.6 ADMINISTRATION SETUP

This menu allows you to designate an IP CAM name, administrator password and other user passwords. Administrators may access all IP CAM functions and settings, while general users may only utilize the **LiveView** view and may not access any of the settings.

	Administratio	on Setup	
Camera Name		IP_CAN	
General User	Account ID	guest	
	Old Password	•••••	
	New Password		(3 to 16 characters required )
	Re-type		
Administrator	Account ID	admin	Ì
	Old Password	•••••	
	New Password		(3 to 16 characters required )
	Re-type		

#### 5.6.1 Camera Name

This allows you to set a name for the IPCAM name that will be displayed on the video for identification purposes.

#### 5.6.2 General User

This menu allows you to change the account ID and password for general users.

Using the General User settings:

Step 1: Enter the user name in the "Account ID" field.Step 2: Enter existing password you wish to change in the "Old Password" field.Step 3: Enter the new password in the "New Password" field.

Step 4: Confirm the password by entering it once more in the "Re-type" field; Step 5: Click on Submit to finish.

#### 5.6.3 Administrator

This menu allows you to change the account ID and password for administrators.

Using the Administrator Settings:

- Step 1: Enter the registered IP CAM name in the "Account ID" field.
- Step 2: Enter you're the password you wish to change in the "Old Password" field.
- Step 3: Enter the new password in the "New Password" field.
- Step 4: Confirm the password by entering it once more in the "Re-type".

Step 5: Click on Submit to finish.

#### 5.7 SOFTWARE UPDATE

This menu allows you to update the IP Cam software online. You may use this feature to update the internal IP CAM software in order to make sure you have the newest version available, as well as updates to fix any software glitches.

Software Update Setup
IP.00
IP_COIL/92.8_F5
Бона

Using the Update Feature:

- Step 1. Camera Name: The system will detect the name of current IP CAM automatically.
- Step 2. Current Version: The system will detect the software version of current IP CAM automatically.
- Step 3. New File Name: The filename (including directory) that you want to upload for update.
  - Step 4. Click Browse... to select the file.
  - Step 5. Check the above settings and then click Submit.
  - Step 6. The system will upload the file right away. It might take 7~10 seconds in LAN of 100Mbps.
- Step 7. The system will count down about 50 seconds automatically. If it succeeds, the message of Update completed! System will auto reset after 3 seconds! will be displayed on the screen.
  - Step 8. After finishing update, please close the window of Internet Explorer and delete

CSQ objects in the following path:

My Computer\Control Panel\Internet Options\Settings...(Figure1)\View Objects...(Figure2)\CSQ Object (Figure3)



#### (Figure1)

Check for newer versions of stored pages: © Every visit to the page © Every time you gtart Internet Explorer © Automatically © Never Temporary Internet files folder Current location: C:\Documents and Settings\01751\Local Settings\Temporary Internet Files\ Amount of disk space to use: 	Check for newer versions of stored pages: © Every visit to the page © Every time you gtart Internet Explorer © Automatically © Never Temporary Internet files folder Current location: C:\Documents and Settings\01751\Local Settings\Temporary Internet Files\ Amount of disk space to use: 	Settings			? ×
Every visit to the page     C Every time you gtart Internet Explorer     Automatically     Never  Temporary Internet files folder  Current location: C:\Documents and Settings\01751\Local Settings\Temporary Internet Files\  Amount of disk space to use:     455   MB  Move Folder Yiew Files View Qbjects	Every visit to the page     Every time you gtart Internet Explorer     Automatically     Never  Temporary Internet files folder Current location: C:\Documents and Settings\01751\Local Settings\Temporary Internet Files\  Amount of disk space to use:     455    MB  Move Folder View Files OK Cancel	Check for	r newer versions c	of stored pages:	
C Every time you <u>s</u> tart Internet Explorer C <u>Automatically</u> Never Temporary Internet files folder Current location: C:\Documents and Settings\01751\Local Settings\Temporary Internet Files\ Amount of <u>disk</u> space to use: 	C Every time you start Internet Explorer C Automatically Never Temporary Internet files folder Current location: C:\Documents and Settings\01751\Local Settings\Temporary Internet Files\ Amount of disk space to use: 	Every	visit to the page		
Automatically     Never  Temporary Internet files folder  Current location: C:\Documents and Settings\01751\Local Settings\Temporary Internet Files\  Amount of disk space to use:      Hove Folder     Yiew Files     View Qbjects	C Automatically Never Temporary Internet files folder Current location: C:\Documents and Settings\01751\Local Settings\Temporary Internet Files\ Amount of disk space to use: 	CEvery	v time you start In'	ternet Explorer	
Image: Never         Temporary Internet files folder         Current location:       C:\Documents and Settings\01751\Local         Settings\Temporary Internet Files\         Amount of disk space to use:               455 ±         MB         Move Folder         View Dijects	Image: Construction of the structure of the	C Autor	natically		
Temporary Internet files folder         Current location:       C:\Documents and Settings\01751\Local         Settings\Temporary Internet Files\         Amount of disk space to use:	Temporary Internet files folder         Current location:       C:\Documents and Settings\01751\Local         Settings\Temporary Internet Files\         Amount of disk space to use:	Neve	r)		
Current location:       C:\Documents and Settings\01751\Local         Settings\Temporary Internet Files\         Amount of disk space to use:	Current location:       C:\Documents and Settings\01751\Local         Settings\Temporary Internet Files\         Amount of disk space to use:               455         Move Folder         View Piles         OK	Temporary Inter	rnet files folder —		
Amount of disk space to use:         -         -         455         Move Folder         View Files	Amount of disk space to use:         -         -         455         Move Folder         View Files         OK	Current location	i: C:\Document Settings\Tem	s and Settings\0175 porary Internet File:	1\Local s\
-     455 ★ MB       Move Folder     View Files	455 ★ MB       Move Folder       View Files       View Qbjects       OK	Amount of disk	space to use:		
Move Folder View Tiles View Objects	Move Folder View Objects OK Cancel			455 🛨	MB
Move Folder View Files View Objects	Move Folder View Tiles View Objects OK Cancel	16			
	OK Cancel	Move Folder.	⊻iew =ile	es View <u>O</u> b	jects
	OK Cancel				
				OK	Cancer



#### (Figure3)

Step 9. Re-login IP CAM and type the Account ID and Password.

Step10. View Current Version to check if the upgrade is successful or not.

Note: After finishing Step 6., do not operate IPCAM and cause it disconnected. Otherwise, it would be damaged and needed to be repaired by factory.

Strongly recommend: Please follow the connection method in 2.2.
 Open the browse and access into network monitoring screen. Then, execute the work of upgrade. (The reason is that the worse stability of the network might cause update failed and damage the device. Then the device would be repaired by the factory.)

#### **APPENDIX**

# APPENDIX A. USING A PPPOE DIALUP CONNECTION AND DDNS WITH THE DN-16023 EZ IPCAM (USING A HUB)

This section is intended to help users connect to a computer to the IP CAM7100 via a hub. It also describes how to connect to ADSL with a PPPoE type IP address and also how to connect to the DN-16023 using DDNS. The directions are as described below:

- A. Apply for a DDNS account using your home computer.
- B. Connect to the DN-16023 with your home computer (using the CAM\_EZ Search Tool).
- C. Setup your DN-16023 to connect via PPPoE, and enter your DDNS settings.
- D. You may now view your EZ IPCAM with DDNS viewer.

#### A. Applying for a DDNS Account with Your Home Computer

To do this, you must first have a Cable/ADSL Ethernet modem (with RJ-45 connectors), and make sure that your broadband provider (ISP) is properly connected to the Internet. Step 1: Turn on your home computer and connect to the Internet. Open Internet Explorer

and type in http://www.dyndns.org/ website.

Step 2: Go to the "Account" Menu, and click on "Create Account".

網址D) 🎒 http://www.dyndn	us.org/account/							Management of the
						Use	er:	Pass:
DynDNS.	.org							Lost Password?   Sign
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		About	Services	Account	Support	Developers	News	
Create Account	YOHE ACC	ount						
Login		Journe						
Lost Password?		П	cornamo <sup>.</sup>			Password		Login
Billing			semano. [					
Account Upgrades				<u>Cr</u>	eate Acco	iunt   L <mark>o</mark> st Pas	ssword?	
SLA								
			Copyright @ Privacy Polic*	≥1999-2005 Dy y   Acceptable	ynamic Networ Use Policy   1	rk Services, Inc. Trademark Notices		

Step 3: Enter the desired account name (the account name "domain" is used in this example). Enter your E-mail address and password application. Click on "Create Account" to complete the application.

set forth in this Acceptable Use Policy ("AUP") and any other operating rules and policies set forth by DynDNS. The AUP comprises

I have read and agree to the Acceptable Use Policy above:

 ~	~ *	100	~	-	~
 : H	er	п	а	ш	е

Username domain

Your username will be used to login to your account and make changes.

#### E-mail Address

E-mail Address Mail Provinces Confirm E-mail Address:

Step 4. mark the following two selects and press Create Account to complete the application



Step 5: If the application is successful, the following shall appear on your screen.

DynDNS.	User Pass Lost Password?   Sign Up Now
	About Services Account Support Developers News
Create Account	Account Created
Lost Password7 Dilling Account Upgrades SLA	Your account, domain, has been created. Directions for activating your account have been sent to µlia@sq.com tw. To complete registration, please follow the directions that you will receive. You must complete these steps within 48 hours to complete your registration. You should receive the confirmation e-mail within a few minutes. Please make certain that your spam filtering allows messages from support@dyndms.org to be delivered. If you have not received this e-mail within an hour or so, request a password reset. Following the instructions in the password reset e-mail will also confirm your new account. If you don't receive the password reset e-mail either, you should check with your e-mail provider to determine why you are not receiving

- Step 6: After your application has been completed successfully, respond by E-mail to confirm, and go back to <u>http://www.dyndns.org/</u> to enter your user name and password.
- Step 7: Go to Dynamic DNS from the "Account" menu, and click on "Add Host". The following should appear:

1	About	Services	Account	Support	Developers
lomain					
Account Settir	ngs				
E-meil:	Mail	From@com			
	Edit	⊃ <u>refs</u>			
	Char	ige Userna	ime		
/isit the service- Your Hosts & 2	-speci Zones	fic pages t ;	by following	) the linked	I service nam
Custom DNS (A	dd Zon	e)			
Domain Registr	<u>ration</u>	Register Do	<u>main</u> )		
Dynamic DNS (	Add Ho	<u>st</u> )			

Step 8: The "Services" menu should automatically appear. Choose your Domain Name

DynDNS.	org			
	About Se	ervices Account Supp	ort Developers New	s
Custom DNS				
Secondary DNS	New Dynamic Dis	SHOSE		
MailHop	Hostname:		aotane com	
Domain Registration	riostilarile.		gorans.com	
Network Monitoring		For your own domain (eg: y	dame-nost.org	n DNS
MyWebHop	IP Address:	61.30.76.31	gotdns.com	
Dynamic DNS	Enable Wildcard		gotdna.org	
Features			ham-radio-op.net	
Support	Mail Exchanger (optional)		homedns.org	
FAQ		Add Host Reset Fr	Inometip.net	
How-To			homein net	
Clients			homelinux com	
Upgrades			homelinux.net	
Add Host			homelinux.org	
Bulk Update			homeunix.com	
Static DNS			homeunix.net	
WebHop			homeunix.org	
Pricing			is-a-geek.com is-a-geek.net	
			i de la compañía de l	

(gotdns.com has been used in this example for your reference).

Step 9: Enter your Host Name (domain has been used in this example for your reference).



Step 10: After the new hostname has successfully created, the following screen should appear:



B. Connecting to the DN-16023 EZ IPCAM with Your Home Computer (Using the CAM\_EZ

#### Search Tool)

Step 1: Please connect the DN-16023 EZ IPCAM to the HUB as shown in following chart



Step 2: Open CAM\_EZ Search. Click on "Update" to begin searching for any DN-16023 EZ IPCAM connected to the local network. The menu should automatically display the EZ IPCAM under the name "DN-16023". It is recommended that you first change its IP address to 192.168.9.1 (factory default). For gateway, it is recommended that you use 192.168.9.254. Click "submit" to update.

05517 Caa			IP Assignment: STATIC Version:IP_Cam_V2.2_F5
Update	]	Exit	ſ
)150F901099 Name IP SubMask	IP_Can 192 168. 9. 1 255. 255. 255. 0	C PPPOE DHCP STATIC	Udp Tool Port 4000
	192 168 9 254	• •	Account@pppoe.com.tw

Step 3: Go to My Computer > Control Panel > Network and Dialup Connection > Local Connection > click on "Preferences (P)".

eneral Support	
Connection	
Status:	Connected
Duration:	00:26:40
Speed:	100.0 Mbps
A <mark>ctivity</mark> Ser	nt — 🧖 — Received
Packets:	224   0
Properties Disat	ble

Step 4: Select "Internet Protocol (TCP/IP)", and click on the preferences (R). Click on "Ok".

Connec	t using:					
This co	NSUST eK/t	froadco	m 44Ux 1L ollowina it	I/1UU Integra	<u>C</u> onfigure	
	Client for I File and F QoS Pacl	Microsol Irinter SH ket Sche rotocol	it Network haring for I eduler (TCP/IP)	S	eleci	
	<u>n</u> stall		Uninsta		P <u>r</u> operties	_
Tran wide acro	smission Co area netwo ss diverse ii	introl Pro ork proto nterconr	otocol/Inte icol that p nected net	ernet Protoco rovides comr works.	ol. The default munication	
				on connocto		

Step 5: Change the IP Address to 192.168.9.2. Change Subnet mask to 255.255.255.0. The default gateway is 192.168.9.254 (Change the IP address to any numbers within the range of 192.168.9.2 – 192.168.9.253). Click on "ok".

Internet Protocol (TCP/IP) P	roperties 🛛 🛛 🔀
General	
You can get IP settings assigned this capability. Otherwise, you ne the appropriate IP settings.	ł automatically if your network supports ed to ask your network administrator for
O <u>O</u> btain an IP address autor	natically
O Use the following IP address	s:
IP address:	192.168.9.2
S <u>u</u> bnet mask:	255 . 255 . 255 . 0
Default gateway:	192.168.9.254
Obtain DNS server address	automatically
● Use the following DNS serv	ver addresses:
Preferred DNS server:	192.168.1.254
<u>A</u> lternate DNS server:	192.168.1.1
	Advanced
	OK Cancel

Step 6: In EZ Search Tool, click on Update once more to search for IPCAM on the local network. Double click on "IP CAM7100" from the list, and your browser will automatically take you to the IP CAM7100 EZ IPCAM login window.

Please refer to <u>P.10</u> for information on how to browse the surveillance video from the IP CAM EZ CAM.



#### C. Changing the IP CAM EZ IPCAM 7100 Settings to PPPoE / Using DDNS

Step 1: Select "Network" to open the network menu. Enter your account ID and password in the appropriate field in "PPPoE" (in this example, we have used Chung Hwa Telecom ADSL for your reference). Click on "Submit".



Step 2: Go to the "Server" menu. Enter the host name, account ID, and password in the appropriate field in "DDNS Server". Click on "Submit" to finish.

	Server Se	tup		
Mail Server	IP/Host	MailServer.com.tw	Authorization 💿 ON 💿 OFF	
	Mail From	MailFrom@com.tw		
	Receipt to	MailTo@com.tw		
	Account ID	Serq_user	Password ******	
FTP Server	IP/Host	FtpServer.com.tw	Port 21	
	Account ID	FtpUserName	Password ******	
	FTP Mode	o Port Mode ●	Pasv Mode	
DDNS Server	Host Name	domain.dyndns.org	(Link to <u>http://www.dyndns.org</u> )	
	Account ID	domain_name	Password ******	
	Status			
NTP Server	IP/Host	192.5.41.40	(Learn more)	
	Time Zone	(GMT+08:00) China, H	Hong Kong, Australia Western, Singapore, Tai	wan,Russia 💌

Step 3: At this time, you must change the IP settings of your home computer back to their original values (automatically retrieve IP address). To do this, click on "Network Neighborhood", right click on the preferences (R). Select your local connection and right click to view the preferences (R).



Step 4: Select "Internet Protocol (TCP/IP)", and click on the preferences (R). Click on "ok".

Connect using: ASUST eK/Broadcom 440x 10/100 Integrated Controller Configure This connection uses the following items: Client for Microsoft Networks Client for Microsoft Networks	General	Authentication Advanced
ASUST eK/Broadcom 440x 10/100 Integrated Controller Configure This connection uses the following items: Client for Microsoft Networks Client for Mic	Connec	tusing:
Configure This connection uses the following items:  Cient for Microsoft Networks  Giffer and Printer Sharing for Microsoft Networks  Giffer and Printer Protocol (Internet Protocol. The default wide area network protocol that provides communication across diverse interconnected networks.  Giffer and Printer and Print	<b>33</b>	SUSTeK/Broadcom 440x 10/100 Integrated Controller
This connection uses the following items: Client for Microsoft Networks File and Printer Sharing for Microsoft Networks Coo Packet Scheduler File and Printer Sharing for Microsoft Networks File and Printer Sharing for Microsoft Networks File and Printer Scheduler File and Pr		Configure
Client for Microsoft Networks File and Printer Sharing for Microsoft Networks	This c <u>o</u>	nnection uses the following items:
Install     Poperties     Poperties     Poperties     Poperties     Poperties     Poperties     Show icon in notification area when connected		Good Packet Schoduler
Transmission Control Protocol/Internet Protocol. The default wide area network protocol that provides communication across diverse interconnected networks.         Image: Show icon in notification area when connected		nstall
Show icon in notification area when connected	Dave	iption
	Desc Tran wide acro	smission Control Protocol/Internet Protocol. The default area network protocol that provides communication is diverse interconnected networks.
	Desc Tran wide acro	smission Control Protocol/Internet Protocol. The default area network protocol that provides communication ss diverse interconnected networks. <u>w</u> icon in notification area when connected

Step 5: Select "automatically retrieve IP Addre	ss (O)" and "Automatically retrieve DNS
server address (B)". Click on "ok".	

Internet	Protocol (TCP/IP) P	roperties 🛛 💽 🔀
General	Alternate Configuration	
You cai this cap the app Ot	n get IP settings assigned bability. Otherwise, you new ropriate IP settings. btain an IP address autom	automatically if your network supports ed to ask your network administrator for atically
00	se the following IP addres:	s
<u>I</u> P ad	ddress:	
Subr	net mask:	
<u>D</u> efa	ult gateway:	
⊙0 ⊙U:	gtain DNS server address se the following DNS serv	automatically er addresses:
Prefe	erred DNS server:	· · · · · · · · · · · · · · · · · · ·
Alter	nate DNS server.	
		Advanced
		OK Cancel

#### D. Using the IP CAM EZ IPCAM 7100 with DDNS Viewer.

Step 1: Open CAM\_EZ Search, and Click on Update. Wait for about 60 seconds (actual time dependant on the quality of your connection), and the IP CAM EZ IPCAM should be detected automatically. Click on the EZ IPCAM to view its IP and Gateway settings. If the system detects a floating IP address, submask, or gateway that cannot be changed, it means that the IP CAM EZ IPCAM on the local network has been successfully connected via a PPPoE connection, as shown below:

Update         Exit           D150 P01093         Mac           Name         IP_Cam           IP         192.168.0.106           SubMask         255.255.0           GateWay         192.168.0.1           Http Port         80	2551P Cam			IP Assignment: STATIC Version:IP_Cam_V2.2_F5
Name         IP_Cam         © PPPOE         Mac         00150F001093           IP         192.468.0.106         DHCP         Udp Tool Firt         4000           SubMask         255.255.0         STATIC         PPPoF Account         71761864@hinet.net           GateWay         192.168.0.1         PPPoF Account         71761864@hinet.net         PPPoF Account           Http Port         80         PPPoF Account         PPPoF Account         PPPoF Account	Update		Exit	]
GateWay 192.168.0.1 71761864@hinet.net	Name IP SubMask	IP_Cam 192.168.0.106 255.255.255.0	PPPOE     O DHCP     STATIC	Mac 00150F001093 Udp Tool F yrt 4000 PPPot Account
	GateWay Http Port	192.168.0.1	5. bka	71761864@hinet.net PPPoE Password *****

At this time, you may select the EZ IPCAM that has been detected. Your browser should

automatically open to the EZ IPCAM login window.

Step 2: You may also view the surveillance video from the IP CAM EZ IPCAM 7100 via a browser from a remote connection (such as your office) by entering a preset DDNS address (such as domain.gotdns.com).



#### APPENDIX B. FAQ General questions for IP Camera

Q1 What is IP Camera?

A: IP Camera is an independent system that can connect to network or wireless network directly. It is different with general camera. It is an all-in-one system with built-in CPU and transmits high-quality video monitoring images via browser control and network. The IP Camera can setup or view the Web browser of remote PC/Notebook through network.

Q2: How many IP Cameras are allowed to be connected in LAN?A: Eight IP Cameras are allowed to be connected in LAN at one time. Transmitting too many packets through LAN might lower down the efficiency of the network.

Q3: What algorithm that DN-16023 uses for compressing images?

A: IP CAM uses JPEG file format to compress the images and uses dynamic JPEG image compressing technology to process dynamic videos. Thus it can ensure both high-quality screen

and high-compression ratio of the images. JPEG is a standard industry image compression technology, which can apply in various programs of browsers and does not need any plug-in software for viewing.

Q4 How can I promote the image quality?

A1: Please make sure the color setting for your monitor display is 16 bits or above. 16 color or 256 color will reduce the image quality for your monitor display and result in bad quality of the video images,

Q5: Can I capture the static images from IP Camera manually?

A: Yes. You can capture the static image form the IP Camera. While browsing the screen on network,

right click the mouse on the static image or click Snapshot button on the screen to save

the picture with another filename. You can click the Re-arrange button on the browser to re-capture the new screen via IP Camera.

Q6: Can I use IP CAM outdoors?

A: The IP CAM is not waterproof. You have to attach waterproof cover on it for using outdoors. By the way, we do not recommend you to do so.

Q7: What kind of network cable is necessary for IP CAM?

A: Standard RJ-45 Category 5 UTP twisted pair is necessary for IP CAM IP CAM to connect 10 Base-T and 100 Base-T network communication.

Q8: Can I use IP CAM as general PC camera?

A: No. DN-16023 IP CAM can connect and transmit through network or wireless network only, and cannot be used with the same usage as a general PC Camera.

- Q9: Why the time setting for the image is incorrect?
- A: Please confirm the setting of SNTP is correct or not, especially Gateway must be able to connect Internet. And make sure SNTP server can work normally. In addition, while initiating the system, it will connect to SNTP sever to synchronize watches. Later it will be performed again for every hour.
- Q10: Why the IP Address cannot be renewed?

A: Please make sure if there is any IP address of certain device uses the same IP address with IP CAM. If yes, please connect IP CAM to your computer to get rid of the interference of other devices. Then, the update of IP address can be carried out.

Q11: Why DN-16023 can be searched by IP Search Tool but cannot be linked by IE browser?

A: The reason is that the configuration for IE Browser is incorrect and results in browsing IP CAM properly. Please close the Proxy server function.

To close the Proxy Server function, please do the following:

Internet  $Options(O) \rightarrow Connections \rightarrow LAN Settings(L)$ , check the box of **Bypass proxy server for local address** 

Q12: If I do not want to use SD card, can I send mail out?

A: Yes, currently, Save in Flash Card and Mail Image can be used at the same time.

Q13: Why the video films cannot be shown from Internet?

A1: The ActiveX control might be invalid. If you use Internet Explorer 4.0 or above, please make sure ActiveX control is invoked on network setting. Please refer to 3.2 LiveView – real time monitoring network browse settings to set your Internet Explorer.

A2: Please make sure your IE browser supports ActiveX control. If you use Internet Explorer 4.0 or old version, you have to upgrade your network browser software to view the video images from IP Camera.

Q14: It seems that my network browser cannot be used with IP CAM smoothly. Why? A1: Please make sure the version of your Internet Explorer is 6.0 or above. If the problem still exists, please visit Microsoft web site for obtaining newest Internet Explorer.

Q15: How can I know the Active X control having been installed in the computer?

A1: Check if the program code of Cam Image Class is installed in C \Windows\Downloaded Program files folder of your hard disk. At the same time, "Installed" should be displayed on the status bar. If the file is not listed on the above folder, please make sure the security settings of Internet Explorer are properly or not. Then reload the web page of IP Camera for trying again.

Q16: Page Error message is shown in the status bar on the left side of the web page of Internet Explorer.

A1: The ActiveX control was not downloaded and installed correctly for the IP Camera. Please check the security settings of Internet Explorer and close it. Restart Internet Explorer and try to browse and login again.

Q17: There is something wrong with the focal distance of DN-16023. How can I improve it?

A1: Focus the IP CAM manually. You can adjust the focal distance to a proper focal length.

Q18: If I forget IP password and IP address, how can I connect and access IP CAM.

A: For the user who forgets IP password and IP address, please press and hold reset for five seconds to return to the factory default settings.

Q19: When I complete the factory default setting recovering, what should I type for Account ID and Password?

A: Account ID= admin Password = password (small letter)

Q20: When the mails cannot be sent out, what things will DN-16023 do for it?

A: If DN-16023 found that the mails could not be sent out due to some reasons, it would stop the action of sending this mail out and return to the status of normal operation. It will not execute the work of retry.

Installation Problems of IP Camera

Q1: Can IP Camera be operated in the environment of virtual IP (general local network)?

A: Sure. DN-16023 IP Camera can be operated in the environment of virtual IP (general local network).

Q2: Can DN-16023 IP Camera be installed inside the firewall of network?A: If the IP Camera is behind the firewall, port 80 usually is used for common web page communication. You can change the port number for the IP Camera with 80 simply. And the system will be active normally. Also, you can modify the firewall settings manually to make IP Camera passing through the firewall easily. Or you can modify the NAT Route setting, and invoke NAT forward function or DMZ function. It can forward the internal packets on the external network to the virtual IP address in the network.

Q3: I cannot connect IP Camera through IE browser.

A1: It might be that the IP address has been used by other device. To solve this problem, you have to disconnect the IP Camera with network. Then, use CAM\_EZ Search to assign another IP address that no device uses to the IP Camera.

A2: Check the LED on the network. Green and orange LEDs should blink. The green LED in the front side will light or dark regularly. If not, please check the connection of the network between two ends.

A3: Please make sure IP address and communication port that you connect are correct. You can use CAM\_EZ Search tool to inspect the settings of IP Camera. Please confirm the gateway settings of IP Camera matching the settings on gateway/router. It might be errors in the gateway, please refer to the description of the gateway.

A4: Please check if there is any conflict happened among the communication port (initialing value =80) of IP Camera, the IP setting/Gateway setting, and your gateway/router. Please modify the settings manually.

A5: If the IP Camera is installed inside LAN (behind NAT Router), then the external Internet Explorer of NAT Router cannot join to this IP Camera. You can modify DMZ or NAT forwarding function of the router to assist the packets in Internet to be directed to this IP Camera correctly. At the same time, you can open DDNS function to make the network address connecting to this IP Camera easily and conveniently.

Q4: The power LED blinks for a long time. What's wrong with it?

A: It might have trouble in power supply. Please make sure the power supply is offered by IP CAM. The specification is DC 5V1A. In addition, please check if power cord connection and power adaptor are installed properly. If there are problems still, please contact with your dealer quickly.

Q5: The network LED indicates there is a problem occurred, why?

A1: It might be something wrong with your network cable. Please make sure the network cable is OK. If the network cable is not normal, please replace a new and normal cable. Then the problem can be solved.

A2: There might be something wrong with the network equipment connecting to IP Camera, e.g., hub or switch. Please make sure the power of these devices is connected correctly. Then, shut down and restart the device for initiating test.

Q6: IP Camera cannot move smoothly in LAN, why?

A1: It might be that a firewall protects it. Please use the highest administrator of the system to inspect the firewall settings. When you want to connect IP Camera of inner network from external network, you probably need to change the firewall settings.

A2: Please make sure there is no conflict between IP Camera and other devices in the network.

A3: The default router might result in such problem. Please check your router's settings and adjust to allow IP Camera connecting to external area of LAN. (For example, you use NAT forwarding or DMZ function of the router to make the inner network connecting to outside world.)

Q7: Why the image is in the black after you properly set up your IP cam?

A: It could be the effected by the safety re-new program from Microsoft, please check with your local dealer for the update information.