

# Digital to Analog Audio Converter

## Dear Customer

Thank you for purchasing this Audio Converter. For optimum performance and safety, please read these instructions carefully before connecting, operating or adjusting this product. Please keep this manual for future reference.

## 1.0 INTRODUCTION

This Digital to Analog Audio Converter is designed for either home or professional audio switching. It converts Coaxial or Toslink digital audio signals to analog L/R audio and available for connection to an external device such as an amplifier via standard RCA-style jacks. This Converter is small in size and quite easy to install.

### 1.1 FEATURES

This Converter has many features that enable it to perform in a superior manner. Among those features you will find:

- Converts Coaxial or Toslink digital audio signals to analog L/R audio
- Supports sampling rate at 32, 44.1, 48 and 96 KHz.
- 24-bit S/PDIF incoming bit stream on left and right channels.
- Provides electromagnetic-noise-free transmission.
- Easy to install and simple to operate.

## 2.0 SPECIFICATION

Singal Input/output	
Input Audio	Coaxial or Toslink digital audio
Output Audio	L/R audio
Input audio connector	Toslink, 1*RCA (Coaxial
Output audiocommector	32,44,1,48 and 96KHZ
Size (L×W×H)	51×41×26MM
Weight	78g
Limited Warranty	1 year Parts and Labor
Operating Temperature	0℃ to +70℃
Operating Humidity	5%to 90%RH (no condensation)
Storage Temperature	-10℃ to +80℃
Storage Humidity	5% to 90%RH(no condensation)
External Power Supply	5v DC @2A
Power Consumption	0.5 watts(max)
Converter Unit	FCC,CE,UL
Power Supply	UL,CE,FCC
AC Power Adapter	US standard,UK Standard and so on
User Manual	English Version

**Note:** Specifications are subjection to change without notice.

## 3.0 PACKAGE CONTENTS

Before attempting to use this unit, please check the packaging and make sure the following items are contained in the shipping carton:

- 1) Main unit (Digital to Analog Audio Converter)
- 2) 5V DC Power Supply
- 3) User's Manual.


#### 4.0 PANEL DESCRIPTIONS

Please study the panel drawings below and familiar with the signal input(s),out(s) and power requirements.

Back Panel:



Upper Panel:



Front Panel:



#### 5.0 CONNECTION AND OPERATION

Before installation, please make sure all devices you wish to connection have been turned off.

- 1) Connect the audio source device to the Converter using appropriate Toslink or Coaxial cables.
- 2) Connect the a/v Receive or Amplifiers to the Converter using appropriate R/L cable.
- 3) Inset the DC side of 5V power supply into the converter and then connect the AC side of the power supply into the wall outlet.

Note: When connected to the Toslink and Coaxial cables at the same time, the product will give priority to Toslink input.

##### 5.1 CONNECTION DIAGRAM

